

Change Rack Location Instructions: Different Size Trays

CHANGE RACK LOCATION (FOR DIFFERENT SIZE TRAYS)

Step 1 – Figure A

Remove plastic plug in the pin location you wish to move the rack to (See figure A). Using a flat head screw driver unscrew cone pin and screw into new pin location. Replace plastic plug in now vacant unused hole. Repeat this process on both sides of rack cone pin locations making sure you use the same hole location on both sides so the rack stays parallel to inside cabinet wall.

Step 2 – Figure B

You will then loosen both hex bolts (do not remove) until top locking bracket can slide free of slots (See figure B). You will push up on bracket and slide it to the next set of slots (or last set) depending on which hole location you have moved your cone pins to. Then let the bracket slide back down into the slot making sure that the bracket is resting on the bolt shaft. Tighten screws with hand tools so as to not strip threads on hex insert. "Power screw drivers are not recommended for this operation".

